

# DCM501

## Akku-Kaffeemaschine



Pos.	Artikel-Nr.	PG	Bezeichnung	Stk.
1	KF00000034	1	Wassertankdeckel	1
2	KF00000033	2	Löffel	1
3	KF00000019	18	Wassertank	1
4	KF00000017	16	Handgriff	1
5	KF00000010	25	Filtergehäuse	1
6	KF00000014	5	Kaffeeschublade	1
7	KF00000013	8	Filter	1
8	KF00000012	10	Filterkasten	1
9	KF00000008	42	Elektronik	1
10	KF00000002	1	Blechschraube 3x12	2
11	KF00000009	29	Heizelement	1
12	KF00000002	1	Blechschraube 3x12	1
13	KF00000003	17	Maschinengehäuse	1
14	KF00000002	1	Blechschraube 3x12	6
15	KF00000002	1	Blechschraube 3x12	3
16	KF00000032	20	Kontaktplatte 14,4/18,0V	1
17	KF00000002	1	Blechschraube 3x12	3
18	KF00000031	18	Kontaktplatte 10,8/12,0V	1
19	KF00000029	18	Batteriegehäuse	1
20	KF00000007	1	Blechschraube 3x10	2
21	KF00000006	11	Kontaktplattenabdeckung	1
22	KF00000002	1	Blechschraube 3x12	2
23	KF00000005	17	Schalter	1
24	KF00000002	1	Blechschraube 3x12	2
25	KF00000001	15	Maschinengehäuseboden	1
25,1	KF00000028	1	Fuss	4
26	KF00000002	1	Blechschraube 3x12	6
27	KF00000021	4	Thermobecherabdeckung	1
			*** Zubehör ***	
Z	KF00000020		Thermobecher "Makita"	1

# DCM501

## Akku-Kaffeemaschine

